



ツインバック モデル19A30031100



表示 番号	新宮品番	LV	部品名称	個数1	個数2	個数3	個数4	メーカー品番	備考
1			Double Bag Support Assembly	1				683-05329	
2			Upright Support	1				683-04519B	
3			Rider Hitch Bracket Assembly	1				689-00304A	
4			Universal Support Bracket	1				783-08129	
5			Left Grass Catcher Cover	1				731-12350	
6			Upper Grass Catcher Cover	1				731-12348A	
7			Window	1				731-12349	
8			Upper Chute Vent Cover	1				731-12354	
9			Upper Chute Support	1				731-12351	
10			Hinge Cover Pin	1				711-06701	
11	970007		グラスバック(1ヶ) LTX1050	2				664-04096B	
12	970019		アッパーシュートホース	1				764-05082	
13	970020		ホースコネクタ	1				731-12353A	
14			Discharge Chute Elbow	1				631-05029	
15	970523		ウイングナット	7				720-04122	
16	970522		スクリュー 5/6-18x1.00	6				710-0276	
17	970524		クレビスピン	1				711-0309A	
18			Pin-Intern Cot-5/8	1				714-0117	